

OEM[®]

Tools for Professionals

Harmonic Balancer Puller Kit

27187

OEM[®]

Tools for Professionals

Harmonic Balancer Puller Kit

Before removing
harmonic balancer it
may be necessary to
remove the radiator.

27187

1. Remove the retainer bolt from the balancer.
2. Carefully choose the proper size bolts that fit holes in balancer.

This kit includes:

- Three black-oxide plated 3/8" x 2" fine 24 pitch bolts
- Three nickel-plated 5/16" x 2" 18 coarse pitch bolts
- Three yellow-plated M8 - 1.25 x 80mm metric bolts
- Three black oxide-plated 3/8" - 16 x 4" coarse bolts
- Bolts for GM 3300 & 3800 V6 Engines

3. Place bolts through the slots in the puller making sure the washer head rests on the flat side of the casting.
4. Carefully thread the bolts into the balancer evenly.
5. Select the flat or pointed cap as needed and fit over the end of the large center forcing screw. Turn forcing screw slowly until balancer is removed.

**Caution: Always wear
safety glasses**



MADE IN TAIWAN