

# **OEM**<sup>®</sup>

Tools for Professionals

## **Bearing Race and Seal Driver Set**

### **27119**

# **OEM**<sup>®</sup>

Tools for Professionals

## **Bearing Race and Seal Driver Set**

- Used to install most standard wheel bearing races and seals.

### **27119**

1. Carefully match installer cone to the bearing race you are installing.
2. Using a mallet tap the race into place making sure the bearing race is fully seated.
3. Do the same for the bearing grease seal.



Caution: Always wear safety glasses

**MADE IN TAIWAN**